

## TECHNICAL SPECIFICATIONS

### AMPLIFIER

Power output ..... Continuous power output of 25 watts per channel min. into 8Ω from 40-20,000 Hz with no more than 0.5% total harmonic distortion

### PHONO frequency response (RIAA equalization)

input sensitivity/impedance ..... 70-15,000 Hz  
PHONO: 2.5mV/50kΩ  
AUX: 150mV/30kΩ  
MIC: 4.5mV/10kΩ  
TAPE MONITOR:  
150mV/30kΩ

Output level/Impedance ..... REC OUT: 150mV/10kΩ  
HEADPHONE: 8-600Ω  
SPEAKER: 8Ω

### TUNER

FM  
Frequency range ..... 88-108 MHz  
Usable sensitivity ..... 3.0μV  
50dB quieting sensitivity ..... mono 20μV  
stereo 90μV

Stereo separation ..... 35dB (at 1 kHz)  
Capture ratio ..... 2.5dB  
Selectivity ..... 50dB  
Signal-to-noise ratio .....  
55μV input ..... 70dB (mono)  
65dB (stereo)

### AM

Frequency range ..... 525-1,620 kHz  
Usable sensitivity ..... 300μV/m (Bar antenna)  
Selectivity ..... 25dB

### CASSETTE

Wow and flutter ..... 0.125% DIN Weighted  
Frequency range ..... 40Hz - 12.5kHz  
(normal tape)  
40Hz - 14kHz  
(Chrome tape)

Signal-to-noise-ratio ..... Dolby NR ON - 60dB  
Dolby NR OFF - 50dB

Channel separation ..... 35dB at 1kHz

MOTOR ..... DC with Electronic Speed Control

COUNTER ..... 3 Digit with push button reset

Spooling Performance with C60 Cassette  
Fast Forward ..... 100 sec.  
Rewind ..... 100 sec.

Erase System: AC Erase  
Recording System: AC Bias 85 kHz  
4 track 2 channel stereo

Memory Rewind operates when counter reaches '000'

### RECORD PLAYER

Wow and flutter ..... 0.15% (WRMS)  
Speed ..... 33 & 45 (r.p.m.)

Platter ..... 310mm (12¼")

Drive system ..... Belt drive

Motor ..... DC servo control

Cartridge ..... Magnetic Audio Technica AT 936

Recommended stylus pressure ..... 3.5gm

Strobe ..... Neon Illuminated

Power Source ..... 230V 50Hz

Power Consumption ..... 75W

"Dolby" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation

Noise Reduction System manufactured under license from Dolby Laboratories Licensing Corporation.

Manufactured in New Zealand by

**THORN EMI**  
Consumer Electronics  
N.Z. Limited

36-38 Hastie Ave, Mangere Bridge, Auckland.  
P.O. Box 59051, Mangere Bridge.

The right is reserved to vary specifications or use alternative materials as may be deemed necessary or desirable at any time.

## HEAD CLEANING

After removing the cassette, press the Play key (leaving the cassette compartment door in the open position) and the Record/Playback and Erase Heads will move upwards giving easier access. Clean the oxide residue from the heads with a soft lint free cloth or cotton bud moistened with alcohol (pure methylated spirit). Do not use any solution other than alcohol or a commercial tape head cleaner.

## CAPSTAN

Press the Stop key to retract the rubber pressure roller from the Capstan, and clean the Capstan with a soft cloth. Never apply alcohol or any other solution to the rubber pressure roller.


## CAUTION:

Keep iron products, magnets or screw drivers away from the heads.

## ACCESS FOR SERVICE

**Models 820 & 851.** Remove the lid from Model 851. Remove the four screws (2 at each end of the cabinet) and slide the cabinet back about 5mm. Lift from the front edge and stand it up behind the chassis after removing mat and platter.



Access to the print side of the circuit boards can be gained by removing the four feet and fixing screws from the under side of the unit and removing the base.



**Model 854.** Remove the record player. This is done by lifting the lid on top of the cabinet to the vertical position and lifting the mat and platter from the player taking care to disengage the rubber drive belt from the motor pulley. Unscrew the front fixing screw for the turntable one turn and slide it to the back of the slot. Lift the front left corner of the turntable base and move it forward until the rear turntable holding bracket comes free of the turntable well. Then continuing to raise the left hand side of the turntable base pivot it backwards on the back right hand corner until the right hand holding bracket comes clear of the turntable well. Disconnect the pick up, motor power supply and neon mains supply leads and lift the turntable clear of the cabinet.

Unscrew the two wooden blocks at either end of the chassis back panel and also the wooden rail immediately below it. Now withdraw the cabinet front flap by sliding it to the rear of the cabinet. Open the two doors to the

record storage section of the cabinet to gain access to the four fixing screws which hold the chassis in place and remove these. Support the chassis with one hand and slide it slowly forward until the escutcheon disengages from the cabinet. Slide it a little further forward until the two screws which locate the back of the chassis disengage from the slots into which they fit. Now move the chassis forward, tilting as necessary to clear the turntable well until the chassis is clear of the cabinet. To reassemble the unit carry out the above procedure in reverse.




To remove the front control panel set all toggle switches in the horizontal position and withdraw control knobs from the shafts. Set the twelve pushbuttons in the out position and place a large bulldog clip over them. This is to ensure that they stay in place when the front panel is removed from the chassis. Unscrew the large nut on the record level control shaft and then remove the four countersunk screws (two at each end of the panel) holding the plastic end caps onto the chassis metalwork. Withdraw the panel forward, taking care that it does not foul any of the controls. Leave the bulldog clip attached to the push buttons.

To re-assemble reverse the procedure taking care that the counter zero push button is not trapped behind the panel.

Check operation of all controls particularly the twelve pushbuttons and the cassette door. Adjustment of the cassette door can be made by unscrewing the knurled knobs and adjusting the position of the door. The two holes used to hold the clear door panel are over size thus allowing adjustment when the door is in position in the panel.


# CASSETTE MECHANISM



# CASSETTE MECHANISM PARTS LIST

PART No.	DESCRIPTION	PART No.	DESCRIPTION	PART No.	DESCRIPTION
1	Main Chassis	51	Counter	101	Steel Ball
2	Head Chassis	52	Leaf Switch	102	—
3	Stop Lever	53	Capstan Screw	103	E Ring
4	REC Lever	54	REW Roller	104	E Ring
5	PLAY Lever	55	FWD Assy.	105	Flat Washer
6	REW Lever	56	Center Idler	106	Flat Washer
7	FF Lever	57	FAS Realease Lever	107	Spring Washer
8	PA Lever	58	FAS Gear Box	108	Screw
9	FAS Stop Lever	59	Cord Clamp	109	Screw
10	Motor Bracket	60	Washer	110	Screw
11	EJ Lock Lever	61	Washer	111	Screw
12	REW Roller Arm	62	Washer	112	Screw
13	Lever Guide	63	Oil Cut	113	Screw
14	REC Safety Plate	64	PVC Tube	114	Screw
15	Casette Hold Spring	65	Support	115	Screw
16	PIANO Main F	66	Pause Lock Pce	116	Screw
17	PIANO Lever D	67	Spacer	117	Screw
18	PIANO LEVER E	68	Reel Base	118	—
19	Cue A	69	Main Belt	119	Screw
20	Flywheel Shaft A	70	FAS Drive Belt	120	Screw
21	Counter Bracket	71	Counter Belt	121	Spring Washer
22	Mech Cover	72	FAS Drive Belt	122	—
23	EJ Arm	73	FAS Belt	123	PS Washer
24	EJ Arm B	74	Motor Cushion	124	PS Washer
25	Damp Arm	75	Flywheel	125	—
26	Cue Review Lever	76	Governor	126	Door interior
27	EJ Lock Lever A	77	S Rubber	127	Window cassette
28	Head Chassis Spring	78	Escutcheon Cover	128	Decoration Screw
29	Brake Plate	79	Pinch Roller Spring	129	Switch Operation Metal
30	Brake Operation Plate	80	Head Chassis Spring	130	LEAF SWITCH
31	Leaf S/W Bracket	81	Center Idler Press Spring	131	REW S/W Plate
32	Washer for spring	82	Brake Spring	132	Solenoid Bracket
33	Idler Clutch A	83	Stop Lever return Spring	133	Solenoid
34	Idler Clutch B	84	BT Spring	134	MS Release Plate
35	Casette Holder	85	Lever return Spring	135	—
36	Casette Spring	86	PA Lever Return Spring	136	Spring Pin
37	Spacer	87	Holder Lock Plate Spring	137	—
38	PIANO Shaft	88	PA Lever return Spring	138	Screw
39	EJ Arm Collar	89	Cue return spring	139	Lever return spring
40	—	90	Center Idler return Spring	140	Key Button Silver
41	Center Idler Collar	91	RWD Roller press Spring	141	Key Button Blue
42	PA Collar	92	EJ Lock Lever release Spring	142	Key Button Red
43	Motor Pulley	93	Head Chassis return Spring		
44	REC Lock Lever Shaft	94	FAS release Lever return spring		
45	Play Lever Bush	95	FWD press Spring		
46	FAS Center Pulley	96	Idler press Spring		
47	Pinch Roller	97	Piano Lever return Spring		
48	Motor	98	Push Lever Spring		
49	REC/PLAY Head	99	Lock Lever Cue Spring		
50	Erase Head	100	Rec/Play Head adjust Spring		


# TURNTABLE MECHANISM PARTS LIST.



# TURNTABLE MECHANISM


PART No.	DESCRIPTION	PART No.	DESCRIPTION
1	TT Sheet	58	PU Assy
2	TT	59	Washer 10 $\phi$
3	Belt	60	LN 10
4	TT Shaft Assy	61	Stopper 2
5	TT Shaft Bracket Assy	62	Rubber
6	Pin	63	FM $\odot$ 4x12
7	BT $\odot$ 3x8	64	See Saw Arm Assy
8	Top Plate Assy	65	See Saw Base Assy
9	Adaptor Shaft	66	Forward Arm Assy
10	FMT $\odot$ 3x6	67	Micro S/W
11	Rej Lever Shaft	68	S/W Arm Assy
12	Rej Lever Shaft	69	FM $\odot$ 3x16
13	S.S. W3	70	Arm Assy
14	F.L.N. 3	71	S/W Lever Assy
15	Mounting Spring	72	5P Lug
16	Moltplain	73	Rubber Bushing
17	Push Button	74	IFC Cam
18	VR Knob	75	IFC Spring
19	R gear Assy	76	Metal Spring
20	Clutch Plate	77	IFC Knob Assy
21	Clutch Guide	78	PU Base Plate
22	E-32	79	Cuing Lever
23	Eccentric Pin	80	E-2
24	Spring Washer	81	Cuing Cap
25	Fibre Washer	82	FM $\odot$ 3x12
26	Fibre Washer	83	Motor Bracket
27	Fibre Washer	84	Cushion Rubber
28	E-4	85	Pipe
29	GS Stud	86	UL Tube
30	GS Eccentric Shaft	87	S.S.W. 2.6
31	GS Arm	88	FM $\odot$ 2.6x12
32	GS Spring	89	Pulley
33	Spring Washer	90	Spring
34	Operation Washer	91	Cuing Arm
35	Operation Arm Assy	92	E-3
36	Operation Base	93	Motor Assy
37	CS Ring	94	Adaptor
38	Kick Lever	95	PC Support
39	Return Spring	96	FM $\odot$ 3x6
40	REJ Spring	97	Washer
41	Reject Cover Assy	98	LN $\phi$ 7 $\phi$
42	Reject Lever Assy	99	Lug
43	Fibre Washer	100	TOW-3
44	S/W Lever Assy	101	Maylar Cap
45	SP Cover Assy	102	Earth Wire Assy
46	Shaft Cover	103	FW 102 $\phi$ x 22 $\phi$
47	VR	104	Eccentric Pin
48	Push S/W	105	Wire Fastener
49	SP S/W Base	106	Neon Lamp
50	Stopper	107	Lug Terminal
51	Arm Rest Assy	108	UL Tube
52	PU Base	109	—
53	Elevation Spring	110	—
54	Elevation Shaft	111	—
55	Elevation Plate	112	—
56	FT $\odot$ 2.6x4	113	T 2x3
57	TDT $\odot$ 3x8	114	FW3.2 $\phi$ x 13 $\phi$

# DIAL STRINGING




## CIRCUIT DESCRIPTION

### BLOCK DIAGRAM (TUNER SECTION)




### BLOCK DIAGRAM (AUDIO SECTION)





## TEST EQUIPMENT REQUIRED

1. AF Oscillator
2. AM Signal generator 30% modulation.
3. Millivolt meter.
4. Distortion meter
5. Oscilloscope.
6. Frequency counter capable of counting up to 100 kHz.
7. FM stereo signal generator capable of 400Hz mono 75kHz deviation and 1kHz stereo 67.5kHz deviation.
8. Standard Reference blank cassette TEAC MTT-502.
9. Dolby NR level calibration cassette TEAC MTT-150 400Hz 200nWb/m.
10. Azimuth 10kHz cassette TEAC MTT-114.



## AM RADIO ADJUSTMENTS


Set function switch to AM.

Connect test equipment to unit as shown above. Set dial pointer to the datum mark at the left hand end of the scale with the gang closed.

1. Short the AM oscillator section of the tuning gang to the frame of the gang.
2. Tune signal generator to 455kHz 30% modulation high output.
3. Advance volume control until a tone is heard and tune the IF Transformers T203 and T204 for maximum reading on the millivoltmeter. Reduce the generator output and repeat the adjustment. Repeat the adjustment a number of times each time reducing the output from the generator and tuning T203 and T204 for maximum on the millivoltmeter. Continue until no further improvement can be obtained.
4. Remove the shorting link from the oscillator section of the gang and tune the receiver and signal generator to 600kHz with an output level of 60dB (1mV).
5. Adjust L207 for maximum output and then the aerial coil L206 for maximum output.
6. Tune the receiver and signal generator to 1400kHz and adjust trimmer TC5 for maximum output and then trimmer TC4 for maximum output.
7. Repeat the adjustments of L207, 206, TC5 and TC4 a number of times each time reducing the output level from the signal generator until no further improvement can be made.
8. Tune the signal generator and receiver to 1000kHz and adjust T204 and T203 for maximum output on a low level signal. This is to ensure that T203 is tuned to exactly the same frequency as T204.

## FM TRACKING ADJUSTMENT


Set function switch to FM and FM mode switch to MONO. MUTE switch OFF.



1. Adjust FM signal generator to 400Hz (mono) 75kHz deviation (100% modulation).
2. With an output of 60-80dB (1-10mV) from the generator at 98MHz tune the receiver to 98Mz.
3. Adjust TC3 for maximum output.
4. With the receiver still tuned to 98MHz reduce the output from the generator to 10-30dB (3-10 $\mu$ V) and adjust TC1 and TC2 for maximum output.
5. Now adjust T201 for maximum output.
6. Increase the output from the stereo signal generator to 60dB (1mV) and adjust T202 for minimum distortion.
7. Reduce the output from the generator to 35dB (50 $\mu$ V) and adjust VR202 until the green tuning indicator lamp comes on.
8. Verify that the red indicator lamp on the right comes on when the receiver is tuned to the right, and that the left lamp comes on when the receiver is tuned to the left.
9. Reduce the output from the generator and tune the receiver through the signal making sure that the Red Lamps either side of the green tuning indicator are balanced at low levels of signal. If not adjust VR202 until this condition is achieved.

## FM MULTIPLEX ADJUSTMENT

Set function switch to FM and FM MODE switch to Stereo. MUTE switch off.



1. Adjust the stereo signal generator (stereo mode of operation) to give an output of 60dB (1mV) at 98MHz with 1kHz modulation and 67.5kHz deviation. Set the pilot signal to 19kHz with 7.5kHz deviation.
2. Tune the receiver to 98MHz.
3. Cut the 1kHz modulation and adjust VR201 for a reading of 19kHz  $\pm$  20Hz on the frequency counter. With the stereo modulation applied to either the Left or the Right Channel only adjust T201 for minimum distortion. (Do not turn T201 more than  $\pm$  90°.)
4. Check that stereo indicator operates when a stereo signal is being received.

## HEAD ADJUSTMENT

The erase head is not adjustable but the Left Hand fixing of the record/play head is spring loaded and adjusting the screw on this side of the head will enable azimuth adjustment to be made. Normally readjustment should not be required unless the factory setting has been disturbed or a replacement head has been fitted.


Access to the adjusting screw is gained by unscrewing the two silver decorative screws on the front of the cassette door and removing the clear plastic door panel. **Note:-** The screw holes in this panel are over size to allow adjustment with the front panel when reassembling. Access to the azimuth screw is gained through the slot beneath the door with the play Key depressed. To adjust the azimuth play a 10kHz azimuth test tape (Teac MTT-114) and adjust the azimuth screw for maximum reading on both LED level displays. Seal the screw with screw locking adhesive. (Do not fill the slot in the head.) Reassemble door panel. Take care to ensure that the panel does not foul the surrounding metal work when in the closed position.

## DOLBY NR PLAYBACK ADJUSTMENT

Select Aux function.

Bias/Equalisation switch to normal.

Dolby NR Switch off.




1. Load the recorder with a Dolby NR level calibration tape (Teac Test Tape MTT-150 400Hz 200nWb/m) and play back.
2. Adjust VR1 and VR2 until the millivolt meters read exactly 1V.

## DOLBY NR LAW ADJUSTMENT

Select Aux function.

Bias/Equalisation switch to normal.

Dolby NR Switch OFF → ON.




1. Apply a 1kHz Signal from the AF Generator.
2. Insert an unrecorded cassette into the recorder and press the Play and Record Keys.
3. Turn the Record level control knobs until the millivoltmeters read 10mV.
4. Press the Dolby NR Switch in and adjust VR3 and VR4 until the millivoltmeters read 20mV (+6dB ± 0.1dB).

## TRAP ADJUSTMENT

Bias and Equalisation switches in the normal position.

Dolby NR switch OFF.



1. Insert an unrecorded cassette into the recorder and press the Play and Record Keys.
2. Turn the Record level control fully anticlockwise.
3. Adjust L3 and L4 for minimum readings on the millivoltmeters. Switching the "OSC" switch, adjust L3 and L4 for equivalent minimum reading on each position of the "OSC" Switch. **NOTE** MPX Filters 1 & 2 and L6 and L7 have been set up in the factory and should not be adjusted.


## BIAS ADJUSTMENT

Select Record mode of operation on tape deck.

Oscillator frequency shift switch in up position.

Bias/equalisation switch normal.

Dolby NR Switch OFF.




1. Adjust core in bias oscillator coil until the frequency display on the counter reads 85kHz.
2. Insert a blank tape and press the pause key for recording.
3. Turn the record level controls VR601-1VR601-2 fully anticlockwise.
4. Adjust VR7 and VR8 for a reading of 3.5mV (350µA). Press Bias Button and check that the level increases to 5.4mV to 5.8mV (540µA to 580µA).

## RECORD/PLAYBACK LEVEL ADJUSTMENT

Select Aux function.

Bias/Equalisation switch to NORMAL.

Dolby NR Switch OFF.




1. Apply a 1kHz- 10dB (316mV) signal to the AUX input.
2. Load a Standard Reference Blank cassette (TEAC MTT502) into the recorder and press the Pause, Record and Play Keys.
3. Turn the record level control VR601-1 and VR601-2 until the output levels at TP3 and TP4 read exactly 1V.
4. Reconnect the millivoltmeters to the collectors of VT3 and VT4 (R85 and R86) and adjust VR5 and VR6 for a reading of approx. - 10dB (316mV). Press the Pause Key and make a recording.
5. Play the recording back and measure the output at TP3 and TP4 for a reading of 1V.
6. If this level is high or low make another recording after having made a small readjustment to VR5 and VR6 until a figure of 1V is achieved on playback at TP3 and TP4.

# RECORD/PLAYBACK FREQUENCY CHARACTERISTIC CHECK


Select Aux function.

Bias/Equalisation switch to normal.

Dolby NR switch off.




1. Apply a 1kHz– 10dB (316mV) signal to the Aux input.
2. Insert a standard Reference Blank Cassette (TEAC MTT502) into the recorder and press the Pause, Record & Play Keys.
3. Turn the record level controls until the millivoltmeters read –25dB (56.2mV) at TP3 and TP4.
4. Depress the Pause Key and make a few seconds recording at 1kHz then change frequency and record at 250Hz, 10kHz and 12.5kHz.
5. Playback and see that the readings are within 3dB at 250Hz, 1kHz and within 4dB at 12.5kHz.




DOLBY NOISE REDUCTION CIRCUIT LIMITS

# PRINTED CIRCUIT BOARD LAYOUTS

## SWITCH PCB




## MIC PCB MEMORY, OSC. PCB




## LED INDICATORS PCB



## POWER AMP PCB





## LED DISPLAY PCB






# PREAMPLIFIER PCB





- S1-1 TO S1-12 RECORD/PLAY SWITCH IN PLAY MODE
- S2-1 TO S2-4 SPEAKER OUTPUT SWITCH IN 'A' POSITION
- S3-1 LOUDNESS IN OFF POSITION
- S3-2 BIAS - CRO - STD IN STD POSITION
- S3-3 EQUILIBRATION - CRO - STD IN STD POSITION
- S3-4 DOLBY NR IN OFF POSITION
- S3-5 EXTERNAL TAPE MONITOR IN OFF POSITION
- S3-6 FM MONO SWITCH IN STEREO MODE
- S4-1 FM MUTE SWITCH IN MUTE ON
- S4-2 FM SELECT ON
- S4-3 AM OFF
- S4-4 AUX - OFF
- S4-5 TAPE - OFF
- S4-6 PHONO - OFF
- S4-7 TO S4-6 ARE INTERLOCKING SWITCHES
- S5 BIAS OSCILLATOR SHIFT
- S6 TAPE MUTE
- S7 PAUSE
- S8 MEMORY REWIND
- S9 COUNTER - MEMORY REWIND FACILITY
- S10 MAINS SWITCH
- S11 TAPE MOTOR SUPPLY SWITCH



THE WORD DOLBY IS A TRADEMARK OF DOLBY LABORATORIES INCORPORATED.

MATERIAL				ISSUE CHANGE	
QTY	CHD	DATE	SCALE	USED ON	DRAWING NO
1	89	8-80		851	THORN
1				820	
1				854	

TITLE CIRCUIT DIAGRAM FOR SYSTEM 80 MUSIC CENTRE WITH DOLBY NR

B1667